



Quick Start Guide


1




2




1



2



3




3



1




2




4


1



2




3




5




1




2




3



TV MENU	
Auto Search	Start
TV System	SECAM
TV Sound	DK
Fine Tune	...
Del. Channel	



6



7

